

# SHORT FORM APPLICATION GUIDE CAFCO® FENDOLITE® TG(Commercial)

(Americas)

## ISOLATEK® Type TG (Commercial)

(Worldwide)

This is an abbreviated guide and is not intended as a substitute for the Long Form CAFCO FENDOLITE M-II & TG (Commercial) / ISOLATEK Type MII & Type TG Application & Installation Manual. Applicator shall completely and fully read and understand the Long Form Application & Installation Manual prior to applying this product.

MIXER REQUIREMENTS: Paddle or ribbon-type mortar mixer with safety cover and provision for quick

dumping of mix Mixers capable of operating speeds of 35 to 40 RPM, are

required.

WATER REQUIREMENTS: One bag of product requires 3.5 to 4.0 US Gal. (13 to 15 L) of potable water

per bag. A calibrated water meter is required to ensure constant water

volume per mix. Note: The "five gallon bucket" method is unacceptable.

MIX TIME: Product is mixed by first adding potable water to the mixer and then

product. Mix for three (3) minutes to achieve the target mixer slurry density. In a multiple bag mix, the mix time begins after the last bag

has been added to the mixer.

Note: Adjustments to the workability of the mix can be made by slightly increasing the amount of water in the mixer. <u>CAFCO</u>

FENDOLITE TG / ISOLATEK Type TG must not be spray applied.

THICKNESS PER COAT:

Apply the CAFCO FENDOLITE TG / ISOLATEK Type TG using

conventional plasterer's tools.

For Single coat applications, apply 1/2 in. (13 mm) to 3/4 in. (19 mm).

For multiple coat applications, a first pass thickness of 1/2 in. (13 mm) will provide a good leveling layer for subsequent coats to build to final thickness.

Apply 3/4 in. (19 mm) to 1 in. (25 mm) on subsequent passes.

In no case may the coating thickness be less than 1/2 in. (13 mm). When applying multiple coats, allow the prior coat to "stiffen" before

applying subsequent coats.

Where more than one coat is required, the preceding coat must be left with a texture or well scratched surface, to ensure good bonding of subsequent coats. 1/8 in. deep x 1/8 in. wide (3mm deep x 3mm wide)

subsequent coats. 1/8 in. deep x 1/8 in. wide (3mm deep x 3mm wide) scratches in two directions at 1 in. (25mm) apart are satisfactory.

It is optimal that subsequent coats, if required, be applied within 48 hours

of application of preceding coat. Note: If the surface of previously applied product becomes dry, it must be pre-wet with a mist of potable water before applying further coats.

FINISHING APPLICATION: Care must be taken to avoid excessive working of the product or

"polishing" the finish. Light, even movements will yield best results. As a general rule, apply as great a thickness as practical to keep number of coats

to a minimum.

Avoid the use of thin finish coats--once a first coat has provided a good key, continue to build further coat (coats) with the final coat at least 1/2 in.

(13mm) thick. Avoid upward featheredges.

APPLICATION TEMPERATURE:

Product must be applied when the temperature is between 40°F (4°C) and relative humidity is above 50%. A minimum substrate and

95°F (35°C) and relative humidity is above 50%. A minimum substrate and ambient temperature of 40°F (4°C) shall be maintained prior to, during and a

minimum of 24 hours after the application.

#### **SURFACE PREPARATION:**

Ensure surfaces are clean and free of dirt, oil, grease, loose mill scale, paints/primers (other than those approved by Isolatek) and any other materials that may impair adhesion. Note: Some substrates require the use of CAFCO® BOND-SEAL / ISOLATEK Type EBS (adhesive), CAFCO® PRE COTE / ISOLATEK Type PC, ISOLATEK® SBK-113, keycoat, and/or mechanical reinforcement. Primed or painted structural steel may adversely affect the bond of spray-applied fire resistive material. When primed or painted structural steel is specified, refer to the guidelines established by the testing laboratory or agency.

**VENTILATION:** 

Provide a minimum of 4 complete air exchanges per hour until the material is dry.

**SAFETY PRECAUTIONS:** 

CAFCO FENDOLITE TG / ISOLATEK Type TG is slippery when mixed with water. Do not allow wet material to remain on scaffolds, ladder rungs or floors. Walking on wet material may result in slips or falls. Signage must be posted in areas where the application of CAFCO FENDOLITE TG / ISOLATEK Type TG is ongoing to warn other trades of slip hazards.

#### **CALCULATING MIXER DENSITIES:**

- Weigh an empty 1036cc cup and tare the scale to account for the cup weight.
- 2. Fill the cup with material from the mixer. Then gently tap the cup on a hard surface to eliminate all air pockets.
- 3. Level the material with top of cup.
- Weigh the filled cup in grams.
- 5. Compare weight in grams to the mixer density in chart below.

### ESTIMATING CAFCO FENDOLITE TG / ISOLATEK Type TG MIXER DENSITY FROM WET CUP WEIGHTS

	MIXER DENSITY Using 3.75 US Gals (14 L) Water	
WET CUP WEIGHT (Grams)	PCF	(kg/m³)
1013	61.0	(977)
1021	61.5	(985)
1029	62.0	(993)
1038	62.5	(1001)
1046	63.0	(1009)
1054	63.5	(1019)
1063	64.0	(1025)

Cup Size = 1036 cc

**NOTE:** Only the listed equipment, nozzles and procedures are approved for applying CAFCO FENDOLITE TG / ISOLATEK Type TG. Deviations from these requirements will result in product not meeting claims as published in the literature. **For additional information, please contact the Technical Service Department.** 



